ZyXEL ATP Series
ZyWALL USG FLEX Series

Quick Start Guide

ENGLISH | DEUTSCH | ESPAÑOL | FRANÇAIS
ITALIANO | ПУССКИЙ | ČESTINA | MAGYAR
POLSKI | SLOVENŠČINA | ROMÂNĂ | PIPCKA | 繁體中文
简体中文 | 繁體中文

Contents

Hardware Installation

Option 1 – On-Cloud Nebula Registration with the App

Option 2 – On-Premises Direct Management

Support Information

Hardware Installation

(1) Use the included power adapter or power cord to connect the device to a power outlet. Turn on the power. If it is recommended that you keep the device turned on. Appliance before using it to protect your network. Use an Ethernet cable to connect the WAN port to an Internet port. Wait for the Sys LED to turn solid green.
Use another Ethernet cable(s) to connect the WAN port (P1) to a LAN port on your broadband modem or router. Wait for the Link LED to turn solid green.
Connect your computer to the LAN port (P2). Wait for the Link LED to turn solid green.
Wait for the Sys LED to turn solid green. Wait for the Link LED to turn solid green.
Use the Security Appliance as configuration, Ensure the as on Jumper Wire Ethernet cable to connect the Security Appliance to your Internet Service Provider's (ISP) Ethernet port. Wait for the Sys LED to turn solid green. Wait for the Link LED to turn solid green.
Use the Ethernet cable to connect the Security Appliance to your computer to complete the initial configuration.
Wait for the Sys LED to turn solid green. Wait for the Link LED to turn solid green.
Use the Ethernet cable to connect the Security Appliance to your Ethernet port.